ASSEMBLY INSTRUCTION
SKU# 7426489

Note: Please consult a qualified electrician if you are not certain of the installation

CAUTION: Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

1. Thread the outlet box screws into mounting strap. Attach the mounting strap by tightening the outlet box screws securely into the outlet box.
2. Connect wire with white to white and black to black, cover the connections by using the wire connectors provided. Tie the ground wire from outlet box and from fixture to the ground screw on the mounting strap.
3. Install bulbs. (not included)
4. Carefully tuck all wiring back into outlet box.. Thread the mounting screws into the appropriate threaded holes in the mounting strap. Locate the ceiling pan over the outlet box, positioning the mounting screw heads through the large opening of keyhole slots. Rotate the ceiling pan to seat the mounting screws and tighten securely.
5. Secure the nipple to the bushing firmly. Place the glass shade over nipple and use cap and finial to tighten the fixture body.
6. Turn on the power.